

SunbriteTV Model 2310(A series),3220, 3230 and 4610

Sony 5 bit device code 1 command set.
Carrier 40.639 khz

Discretes in hex from pronto ccf file

Power on

0000 0066 0000 000d 0061 0018 0018 0018 0030 0018 0030 0018 0030 0018 0018 0018
0030 0018 0018 0018 0030 0018 0018 0018 0018 0018 0018 0018 0018 0018 0417

Power off

0000 0066 0000 000d 0061 0018 0030 0018 0030 0018 0030 0018 0030 0018 0018 0018
0030 0018 0018 0018 0030 0018 0018 0018 0018 0018 0018 0018 0018 0018 0417

Tuner

0000 0066 0000 000d 0061 0018 0018 0018 0018 0018 0018 0018 0018 0018 0018 0018
0018 0018 0030 0018 0030 0018 0018 0018 0018 0018 0018 0018 0018 0018 0417

Input 1 (Composite Video 1)

0000 0066 0000 000d 0061 0018 0030 0018 0018 0018 0018 0018 0018 0018 0018 0018
0018 0018 0030 0018 0030 0018 0018 0018 0018 0018 0018 0018 0018 0018 0417

Input 2 (Svideo 1)

0000 0066 0000 000d 0061 0018 0018 0018 0030 0018 0018 0018 0018 0018 0018 0018
0018 0018 0030 0018 0030 0018 0018 0018 0018 0018 0018 0018 0018 0018 0417

Input 3 (Composite Video 2)

0000 0066 0000 000d 0061 0018 0030 0018 0030 0018 0018 0018 0018 0018 0018 0018
0018 0018 0030 0018 0030 0018 0018 0018 0018 0018 0018 0018 0018 0018 0417

Input 4 (Svideo 2)

0000 0066 0000 000d 0061 0018 0018 0018 0018 0018 0030 0018 0018 0018 0018 0018
0018 0018 0030 0018 0030 0018 0018 0018 0018 0018 0018 0018 0018 0018 0417

Input 5 (Component 1)

0000 0066 0000 000d 0061 0018 0030 0018 0018 0018 0030 0018 0018 0018 0018 0018
0018 0018 0030 0018 0030 0018 0018 0018 0018 0018 0018 0018 0018 0018 0417

Input 6 (Component 2)

0000 0066 0000 000d 0061 0018 0018 0018 0030 0018 0030 0018 0018 0018 0018 0018
0018 0018 0030 0018 0030 0018 0018 0018 0018 0018 0018 0018 0018 0018 0417

Input 7 (VGA)

0000 0066 0000 000d 0061 0018 0030 0018 0030 0018 0030 0018 0018 0018 0018 0018
0018 0018 0030 0018 0030 0018 0018 0018 0018 0018 0018 0018 0018 0018 0417

Input 8 (Hdmi1)

0000 0066 0000 000d 0061 0018 0018 0018 0018 0018 0018 0018 0030 0018 0018 0018
0018 0018 0030 0018 0030 0018 0018 0018 0018 0018 0018 0018 0018 0018 0417

Input 9 (hdmi2)

0000 0066 0000 000d 0061 0018 0030 0018 0018 0018 0018 0018 0030 0018 0018 0018
0018 0018 0030 0018 0030 0018 0018 0018 0018 0018 0018 0018 0018 0018 0417

SunbriteTV Model 3220 and 4610

Sony 5 bit device code 1 command set.
Carrier 40.639 khz

Command Code Remote Function

0	1
1	2
2	3
3	4
4	5
5	6
6	7
7	8
8	9
9	0
10	
11	Enter
12	
13	
14	
15	
16	Channel Up
17	Channel Down
18	Volume Up
19	Volume Down
20	Mute
21	Power
22	Exit
23	MTS
24	FAVORITE -
25	
26	
27	
28	
29	
30	PIP VIDEO
31	CHANNEL LOCK
32	- (DASH)
33	
34	PIP SOURCE
35	CC
36	ADD/DELETE
37	SOURCE
38	
39	
40	
41	SOUND
42	FAVORITE ADD/DELETE
43	
44	
45	PIP AUDIO
46	Power On
47	Power Off

48
49
50
51 RIGHT ARROW
52 LEFT ARROW
54 Sleep
56
58
59 CH RETURN
60 INFO
62
63
64 SunbriteTV Tuner
65 SunbriteTV Input1, CV1
66 SunbriteTV Input2, SV1
67 SunbriteTV Input3, CV2
68 SunbriteTV Input4, SV2
69 SunbriteTV Input5, Component1
70 SunbriteTV Input6, Component2
71 SunbriteTV Input7, VGA
72 SunbriteTV Input8, HDMI1
73 SunbriteTV Input9, HDMI2
76
77
78 PIP SIZE
79 PIP POSITION
80
81
88
89
90 Picture
91
92 Pip On/Off
93 DNR
94
95
96 MENU
97
98 ASPECT
99 SRS
100 Freeze
101 GUIDE
102
103
104
106
107
108
110
111
112
113
114
115
116 UP ARROW
117 DOWN ARROW
120

121
124
125
127